









Baritone Saxophone

BC8403-1 (lacquer), BC8403-4 (matte)

Spare Parts and Accessories



Baritone Saxophone (continued)

BC8403-1 (lacquer), BC8403-4 (matte)

Spare Parts and Accessories

<p>Adjusting Screw</p>  <p>BCS8403-304L lacquer</p> <p>BCS8403-304M matte</p>	<p>G# Adjuster</p>  <p>BCS8403-305L lacquer BCS8403-305M matte</p>	<p>Adjusting Lug</p>  <p>BCS8403-3051L lacquer</p> <p>BCS8403-3051M matte</p>
<p>Long Keyguard Screw</p>  <p>BCS8403-3081L lacquer</p> <p>BCS8403-3081M matte</p>	<p>Short Keyguard Screw</p>  <p>BCS8403-3082L lacquer</p> <p>BCS8403-3082M matte</p>	<p>Right Hand Key Guard</p>  <p>BCS8403-109L lacquer</p> <p>BCS8403-109M matte</p>
<p>Key Guards</p>  <p>lacquer: matte:</p> <p>Eb Key Guard (Small): BCS8403-1071L BCS8403-1071M</p> <p>C = C# Key Guard (Medium): BCS8403-1072L BCS8403-1072M</p> <p>B = Bb = A Key Guard (Large): BCS8403-1073L BCS8403-1073M</p>		
<p>Bumper Felt</p>  <p>BCS8201-403</p>	<p>Rod Guard</p>  <p>BCS8403-119L lacquer BCS8403-119M matte</p>	<p>Point Screw</p>  <p>BCS8403-301</p>
<p>Spring Set</p>  <p>BCS8403-316</p>	<p>Pearl Set</p>  <p>BCS8403-401</p>	<p>Roller Set</p>  <p>BCS8403-402</p>
<p>Pad Set</p>  <p>BCS405B</p>	<p>Strap</p>  <p>BCS8403-500</p>	<p>Case</p>  <p>BCA8003</p>